

Quick Troubleshooting Chart

Product Model: Garden Controls Cycle Timer


BEFORE YOU START

- Put slide switch to "Day Mode"
- Put both knobs to 10 min
- Have a load to plug into UNIT*

○ = Steps

DEFINITIONS

Indicator: Output ON Light Indicator



*Before test, check if load is working properly.